



**Kurz-Kasch, Inc.**

Electronics Division  
Box 1246  
2876 Culver Ave.  
Dayton, Ohio 45401  
Telephone (513) 296-0330

# Operating Instructions

## For Model

101 A

~~PONG DOUBLES~~

Atari

		SL2				START 2			SR2				5V
		x				x	x		x				
LLP	SL1	SL5	SL3	LRP		START 1	RLP	SR1	SR5	SR3	RRP	ON	OFF
x	x	x	x	x	x	x	x	x	x	x	x		
		SL4							SR4				
		x							x				
	SL6		SL7			COIN		SR6		SR7		POWER	
	x		x			x		x		x	x	ON	OFF

1. Insert program card with number facing you in slots A or B, as marked.
2. Power on
3. Coin
4. Start 1
5. LLP - left-left paddle control
6. LRP - left-right paddle control
7. RLP - right-left paddle control
8. RRP - right-right paddle control