




Kurz-Kasch, Inc.

Electronics Division
Box 1246 • 2271 Arbor Blvd.
Dayton, Ohio 45439
Telephone (513) 299-0990

Operating Instructions

For Model 322AB - 287C or 171C
ASTEROIDS
ATARI



1. Insert the 322B card into Program "B" connector, number side up.
2. Insert the 322A card into Program "A" connector, number side up.
3. Connect a speaker to the speaker leads.
4. Insert a 287C or 171C card into the test fixture.
5. Insert the ASTROIDS game board into the "C" card connector.

NOTE: There will not be any video on the monitor. An oscilloscope can be connected to the X, Y and Z outputs from the game board.

6. Slide the +5 Volt switch to "ON".
7. Slide the POWER switch to "ON".
8. PUSH:

COIN	for	Right Coin
SR-7		Center Coin
SR-6		Left Coin
START 1		1 Player
Start 2		2 Player
SL-5		Fire
SL-3		Rotate Right
SL-1		Rotate Left
SL-6		Thrust
SL-7		Hyperspace
SR-5		Slam