



# Kurz-Kasch, Inc.

Electronics Division  
Box 1246 • 2271 Arbor Blvd.  
Dayton, Ohio 45439  
Telephone (513) 299-0990

## Operating Instructions

For Model 406A

SUPER PAC MAN

MIDWAY

|     |     |     |     |     |   |         |     |     |     |     |     |       |     |
|-----|-----|-----|-----|-----|---|---------|-----|-----|-----|-----|-----|-------|-----|
|     |     | SL2 |     |     |   | START 2 |     |     | SR2 |     |     | 5V    |     |
|     |     | x   |     |     |   | x       |     |     | x   |     |     |       |     |
| LLP | SL1 | SL5 | SL3 | LRP |   | START1  | RLP | SR1 | SR5 | SR3 | RRP | ON    | OFF |
|     | x   | x   | x   |     |   |         |     | x   | x   | x   |     |       |     |
| x   |     | SL4 |     | x   | x | x       | x   |     | SR4 |     | x   |       |     |
|     |     | x   |     |     |   |         |     |     | x   |     |     |       |     |
|     | SL6 |     | SL7 |     |   | COIN    |     | SR6 |     | SR7 |     | POWER |     |
|     | x   |     | x   |     |   | x       |     | x   |     | x   | x   | ON    | OFF |

1. Insert 406A card into slot "A" number side up.
2. Connect 11-pin connector to circuit board, note the key position.
3. Connect 9-pin connector to circuit board, note the key position.
4. Connect 20-pin connector to circuit board, note key position.
5. Connect 10-pin connector to circuit board, note key position.
6. Turn 5V and power to ON position.
7. Controls are:

```

COIN-----COIN 1
SR6-----COIN 2
START 1-----PLAYER 1 START
START 2-----PLAYER 2 START
SR1-----MOVE LEFT
SR2-----MOVE UP
SR3-----MOVE RIGHT
SR4-----MOVE DOWN
SR5-----MOVE FAST WHEN SUPER PAC MAN
SL1-----MOVE LEFT
SL2-----MOVE UP
SL3-----MOVE RIGHT
SL4-----MOVE DOWN
SL5-----MOVE FAST WHEN SUPER PAC MAN
SL6-----TILT SWITCH
SL7-----SERVICE SWITCH
TEST SWITCH IS ON CARD.

```

} 2-player  
cocktail mode

8. Connect speaker to short wires on 9-pin connector.