



**Kurz-Kasch, Inc.**


Electronics Division  
 Box 1246  
 2876 Culver Ave.  
 Dayton, Ohio 45401  
 Telephone (513) 296-0330

# Operating Instructions

## For Model 213 A, B

BREAKOUT

Atari



1. Insert 213A card into program "A" connector, number side up.
2. Insert 213B card into program "B" connector, number side up.
3. Insert game board into test fixture using 22 pin orientation.
4. Push POWER switch to ON.
5. Push COIN switch once for 1 player, twice for 2 players.
6. Push START 1 switch for 1 player, START 2 for 2 players.
7. SERVE BALL is SR5.
8. LLP is paddle for 1 and 2 players.