



Kurz-Kasch, Inc.

Electronics Division
Box 1246 • 2271 Arbor Blvd.
Dayton, Ohio 45439
Telephone (513) 299-0990

Operating Instructions

For Model


365A

TM100R

SCRAMBLE/SUPER COBRA

STERN

TURTLES



1. Insert 365A program card into "A" connector on TF-650, number side up.
2. Connect cable connector to GAMEBOARD with RED DOT facing up.
3. Connect speaker across 6 inch pigtail leads on cable connector.
4. Slide 5 VOLT switch to ON.
5. Slide POWER switch to ON.
6. Controls are:

COIN is COIN 1
 SR 6 is COIN 2
 START 1 is 1 PLAYER START
 START 2 is 2 PLAYER START
 SR1 is 1 PLAYER LEFT
 SR2 is 1 PLAYER UP
 SR3 is 1 PLAYER RIGHT
 SR4 is 1 PLAYER DOWN
 SR5 is 1 PLAYER SHOOT 1
 SR7 is 1 PLAYER SHOOT 2
 SL1 is 2 PLAYER LEFT
 SL2 is 2 PLAYER UP
 SL3 is 2 PLAYER RIGHT
 SL4 is 2 PLAYER DOWN
 SL5 is 2 PLAYER SHOOT 1
 SL7 is 2 PLAYER SHOOT 2
 SL6 is SERVICE SWITCH

SIGNATURES-----SCRAMBLE

<u>LOCATION</u>	<u>MARKING</u>	<u>SIGNATURE</u>	<u>PERSONALITY BOARD</u>	<u>TYPE</u>
2C	RA2	OC30	2716/I24	HN462716
2E	RA2	PP75	2716/I24	HN462716
2F	RA2	7UH8	2716/I24	HN462716
2H	RA2	A2FH	2716/I24	HN462716
2J	RA2	917C	2716/I24	HN462716
2L	RA2	406A	2716/I24	HN462716
2M	RA2	40HU	2716/I24	HN462716
2P	RA2	89FA	2716/I24	HN462716
5F	RA1	6H98	2716/I24	HN462716
5H	RA1	UF17	2716/I24	HN462716
5C	RA1	U7P3	2716/I24	HN462716
5D	RA1	6150	2716/I24	HN462716
5E	RA1	369F	2716/I24	HN462716

SIGNATURES-----SUPER COBRA

<u>LOCATION</u>	<u>MARKING</u>	<u>SIGNATURE</u>	<u>PERSONALITY BOARD</u>	<u>TYPE</u>
2C	RA1	HC2P	2732/M24	HN462732
2E	RA1	C2P3	2732/M24	HN462732
2F	RA1	9108	2732/M24	HN462732
2H	RA1	7PCF	2732/M24	HN462732
2J	RA1	UP37	2732/M24	HN462732
2L	RA1	55UU	2732/M24	HN462732
5F	RA1	P6AA	2732/M24	HN462732
5H	RA1	42UP	2732/M24	HN462732