



Kurz-Kasch, Inc.

Electronics Division
Box 1246
2876 Culver Ave.
Dayton, Ohio 45401
Telephone (513) 296-0330

Operating Instructions

For Model 104 A

GOTCHA

Atari

		SL2				START 2								5V
		x				x	x							
LLP	SL1	SL5	SL3	LRP		START 1	RLP	SR1	SR5	SR3	RRP	ON	OFF	
	x	x	x	x	x	x	x	x	x	x	x			
		SL4							SR4					
		x												
	SL6		SL7			COIN		SR6		SR7		POWER		
	x					x		x		x	x	ON	OFF	

1. Insert program card with number facing you in slots A or B, as marked.

2. Power on

3. Coin

4. Start 1

5. Character Movement (square)

UP - SR2
 DOWN - SR4
 RIGHT - SR3
 LEFT - SR1

6. Character Movement (cross)

UP - SL2
 DOWN - SL4
 RIGHT - SL3
 LEFT - SL1