



**Kurz-Kasch, Inc.**

Electronics Division  
 Box 1246  
 1501 Webster Street  
 Dayton, Ohio 45401  
 Telephone (513) 223-8161


# Operating Instructions

For Model

287ABC

SPRINT I

ATARI



1. Insert the 287B card into the program B connector, number side up.
2. Insert the 287A card into the program A connector, number side up.
3. Insert the 287C card into the test fixture, number side up.
4. Insert the Sprint I game board into the 287C card.
5. Connect a speaker to the speaker leads.
6. Slide the POWER switch to ON.
7. Press COIN or SR-6 to coin the game.
8. Press START 1 to start the game.
9.
 

SR-5	Steer Right
SL-5	Steer Left
SL-6	Gas
SL-1	1st
SL-2	2nd
SL-3	3rd
10. Press SR-7 for test.