



**Kurz-Kasch, Inc.**

Electronics Division  
 Box 1246  
 2876 Culver Ave.  
 Dayton, Ohio 45401  
 Telephone (513) 296-0330

# Operating Instructions For Model 150 A

PLANT

Midway

		SL2				START 2			SR2				5V
		x				x	x		x				
LLP	SL1	SL5	SL3	LRP		START 1	RLP	SR1	SR5	SR3	RRP	ON	OFF
	x	x	x		x	x	x	x	x	x	x		
		SL4							SR4				
		x							x				
	SL6		SL7			COIN		SR6		SR7		POWER	
	x		x			x		x		x	x	ON	OFF

1. Insert 150 A card into program "A" connector with number side up.
2. Insert computer board into test fixture using 24 pin orientation.
3. Push coin switch once, LED will light.
4. Push start 1 switch once.
5. RRP is right paddle vertical movement  
 LLP is left paddle vertical movement  
 RLP is right paddle horizontal movement  
 LRP is left paddle horizontal movement  
 NOTE: Paddle adjustment controls on computer board are very sensitive because of interaction.
6. SR6 is ball speed, up for normal speed, down for increased speed.
7. Tilt switch is SR5.
8. GO is game over LED on 150 A card.