



KURZ-KASCH INC.
ELECTRONICS DIVISION
2271 ARBOR BLVD.
DAYTON, OHIO 45133

Operating Instructions

For Model 294AB, 265C
SUPER BREAKOUT
ATARI

		SL2				START 2			SR2				5V
		x				x			x				
LLP	SL1	SL5	SL3	LRP		START 1	RLP	SR1	SR5	SR3	RRP	ON	OFF
x	x	x	x	x	x	x	x	x	x	x	x		
		SL4							SR4				
		x							x				
	SL6		SL7			COIN		SR6		SR7		POWER	
	x		x			x		x		x	x	ON	OFF

1. Insert the 294B card into the program B connector, number side up.
2. Insert the 294A card into the program A connector, number side up.
3. Insert the 265C card into the test fixture, number side up.
4. Insert the SUPER BREAKOUT game board into the 265C card.
5. Connect a speaker to the speaker leads.
6. Slide the power switch to ON.
7. Press:
 - COIN for Coin 1
 - SR-6 for Coin 2
 - START 1 for Start 1
 - START 2 for Start 2
8.
 - SEL 1 Cavity SL-6
 - SEL 2 Double SL-7

SL-6 or SL-7 must be held until the ball is served.

9.
 - SERVE SL-5
 - PADDLE LRP
 - TEST SR-5
 - SLAM SR-7