



**Kurz-Kasch, Inc.**

Electronics Division  
 Box 1246  
 1501 Webster Street  
 Dayton, Ohio 45401  
 Telephone (513)223-8161

# Operating Instructions

## For Model

265ABC

SUPER BUG

ATARI

	SL2			START 2		SR2		5V					
LLP	SL1	x	SL3	LRP	x	x	RLP	SR1	x	SR3	RRP	ON	OFF
		SL5			START 1			SR5	x	x			
x		x	x	x	x	x	x	x	x	x	x		
		SL4						SR4					
	SL6	x	SL7	COIN		SR6		SR7				POWER	
	x		x	x		x		x		x	x	ON	OFF

1. Insert the 265B card into the Program B connector, number side up.
2. Insert the 265A card into the Program A connector, number side up.
3. Insert the 265C card into the test fixture, number side up.
4. Insert the Super Bug game board into the 265C card.
5. Connect a speaker to the speaker leads.
6. Slide the power switch to "ON"
7. Press:
  - COIN or SR-6 to coin game
  - SL-7 to select track
  - START to start game
  - START--2 to reset game
  - SR-7 to reset score
8.
  - SL-1 1st
  - SL-2 2nd
  - SL-3 3rd
  - SL-6 Gas
  - SL-5 Left
  - SR-5 Right