



Kurz-Kasch, Inc.

Electronics Division
Box 1246
1501 Webster Street
Dayton, Ohio 45401
Telephone (513) 223-8161


Operating Instructions

For Model

268A, 185B, 222C

M-4 TANK

MIDWAY



1. Insert the 185B card into the program "B" connector, number side up.
2. Insert the 268A card into the program "A" connector, number side up.
3. Insert the 222C card into the test fixture, number side up.
4. Insert the M-4 Tank game board into the 222C card.
5. Connect the two cables from the 268A card to the game board.
6. Connect speakers to the speaker leads.
7. Slide the +5 Volt switch to "ON".
8. Slide the POWER switch to "ON".
9. Press COIN to coin the game. Select one or two players with the switch on the 268A card.

START 2 is reset.

- | | | | |
|-----|--------------------|--------|---------------------|
| 10. | <u>LEFT PLAYER</u> | | <u>RIGHT PLAYER</u> |
| | SL-2 | UP | SR-2 |
| | SL-4 | DOWN | SR-4 |
| | SL-5 | FIRE | SR-5 |
| | SL-7 | RELOAD | SR-7 |