



Kurz-Kasch, Inc.
 Electronics Division
 Box 1246
 1501 Webster Street
 Dayton, Ohio 45401
 Telephone (513) 223-8161

Operating Instructions

For Model 261AB

Drag Race

Kee Games

		SL2				START 2			SR2				5V
LLP	SL1	x	SL3	LRP	x	x	RLP	SR1	x	SR3	RRP	ON	OFF
		SL5	x			START 1		SR5	x	x			
x		x	x	x	x	x	x	x	x		x		
		SL4						SR4					
		x						x					
	SL6		SL7			COIN		SR6		SR7		POWER	
	x		x			x		x		x	x	ON	OFF

1. Insert 261B card into program "B" connector, number side up.
2. Insert 261A card into program "A" connector, number side up.
3. Insert Drag Race game board into test fixture, using 22 pin orientation.
4. Connect speakers to the speaker leads.
5. Connect a voltmeter to the green TACH wire.
6. Slide the 5 Volt switch to "ON".
7. Slide the POWER switch to "ON".
8. Push COIN once for 1 player, twice for 2 players.
9. Push START 1 or START 2 to start game.
10. The slide switch on the 261A card selects which car can be steered.

11.	<u>CAR 2</u>		<u>CAR 1</u>
	SL-1	1st	SR-1
	SL-2	2nd	SR-2
	SL-3	3rd	SR-3
	SL-4	4th	SR-4
	SL-6	ACCEL.	SR-6
	SL-5	STEER LEFT	
		STEER RIGHT	SR-5