



Kurz-Kasch, Inc.

Electronics Division
 Box 1246
 2876 Culver Ave.
 Dayton, Ohio 45401
 Telephone (513) 296-0330

Operating Instructions For Model

161 A & B

HOCKEY

Ramtek

		SL2				START 2			SR2				5V
		x				x	x		x				
LLP	SL1	SL5	SL3	LRP		START 1	RLP	SR1	SR5	SR3	RRP	ON	OFF
x	x	x	x		x	x	x	x	x	x	x		
		SL4							SR4				
	SL6	x		SL7		COIN		SR6	x	SR7		POWER	
	x		x			x		x		x	x	ON	OFF

1. Insert 161 A card into program "A" connector with number side up.
 Insert 161 B card into program "B" connector with number side up.
2. Insert board to be tested into test fixture keeping edge connector all the way to the left, as you face connector.
3. Turn power switch on.
4. Push coin switch once.
5. LLP is left paddle.
 RRP is right paddle.