



Kurz-Kasch, Inc.

Electronics Division
Box 1246

1501 Webster Street
Dayton, Ohio 45401

Telephone (513) 223-8161

Operating Instructions

For Model 262A

Guided Missile

Midway

		SL2			START 2			SR2				5V	
		x			x	x		x					
LLP	SL1	SL5	SL3	LRP			RLP	SR1	SR5	SR3	RRP	ON	OFF
	x	x	x			START 1		x	x	x			
x		SL4		x	x	x	x		SR4		x		
		x							SR6				
	SL6		SL7		COIN			SR6		SR7		POWER	
	x		x		x			x		x	x	ON	OFF
												ON	OFF

1. Insert 185B card into program "B" connector, number side up.
2. Insert 262A card into program "A" connector, number side up.
3. Using a 222C card, insert the Guided Missile game board into the test fixture.
4. Connect the 10 pin and 15 pin Molex connector to the game board.
5. Connect ungrounded speakers to the red speaker leads.
6. Slide the 5 Volt switch to "ON".
7. Slide the POWER switch to "ON".
8. Select 1 or 2 players with the switch on the 262A card.

9.

LEFT MISSILE		RIGHT MISSILE
SL-1	MOVE MISSILE LEFT	SR-1
SL-3	MOVE MISSILE RIGHT	SR-3
SL-5	FIRE	SL-5