



Kurz-Kasch, Inc.

Electronics Division
 Box 1246
 1501 Webster Street
 Dayton, Ohio 45401
 Telephone (513) 223-8161

Operating Instructions For Model 263A

M-79 AMBUSH

Ranteck

		SL2				START 2			SR2			5V	
		x				x	x		x				
LLP	SL1	SL5	SL3	LRP		START 1	RLP	SR1	SR5	SR3	RRP	ON	OFF
x	x	x	x	x	x	x	x	x	x	x	x		
		SL4							SR4				
		x							x				
	SL6		SL7			COIN		SR6		SR7		POWER	
	x		x			x		x		x	x	ON	OFF

1. Insert 263A card into program "A" connector, number side up.
2. Connect the 4 Molex connectors to the M-79 AMBUSH game board. Both boards must be connected together with the 25 pin ribbon cable used in the game.
3. Connect an ungrounded speaker to the speaker leads.
4. **NOTICE!!!** DO NOT turn on the 5V supply, as the test fixture and/or program card will be damaged!
5. Slide the POWER switch to "ON".

6.	<u>GUN A</u>		<u>GUN B</u>
	SL-1	Gun Position	SR-1
	SL-2	Gun Position	SR-2
	SL-3	Gun Position	SR-3
	SL-4	Gun Position	SR-4
	SL-6	Gun Position	SR-6
	SL-5	FIRE	SR-5