



Kurz-Kasch, Inc.

Electronics Division
 Box 1246
 2876 Culver Ave.
 Dayton, Ohio 45401
 Telephone (513) 296-0330

Operating Instructions

For Model 109 A, 109 B

WENNER IV

Midway

	SL2				START 2			SR 2				5 V	
		x			x	x		x					
LLP	SL1	SL5	SL3	LRP		START 1	RLP	SR1	SR5	SR3	RRP	ON	OFF
	x	x	x	x	x	x	x	x	x	x	x		
		SL4							SR4				
		x							x				
	SL6		SL7		COIN			SR6		SR7		POWER	
	x		x		x			x		x	x	ON	OFF

1. Insert Program Card 109 A into Program "A" connector
 Insert Program Card 109 B into Program "B" connector
2. Insert board to be tested into test fixture using 24 pin orientation
3. Turn power switch on
4. Push coin switch once for 2 player
 Push coin switch twice for 4 player
5. Push start 1 switch once
6. LLP is left paddle
 RRP is right paddle
 LRP is left right paddle
 RLP is right left paddle