



Kurz-Kasch, Inc.

Electronics Division
Box 1246 • 2271 Arbor Blvd.
Dayton, Ohio 45439
Telephone (513) 299-0990


Operating Instructions

For Model

332A/332B

WIZARD OF WAR

MIDWAY



1. Insert 332B program card into "B" connector on TF-650 with number side up. Connect 9-pin connector to power supply header on cage.
2. Insert 332A program card into "A" connector on TF-650 with number side up.
3. Connect 21 and 28 pin connectors from 332A card to ~~COIN~~ GAME BOARD connectors J1 and J2. Connect GND CLIP to card cage.

4. Slide 5-VOLT switch to ON.

5. Slide POWER switch to ON.

6. COIN is COIN 1.
SR6 is COIN 2.

7. START 1 is 1 PLAYER.
SL7 is 2 PLAYER.

8. 1 & 2 PLAYER UPRIGHT

SL1 is LEFT
SL2 is UP
SL3 is RIGHT
SL4 is DOWN
SL5 is FIRE

2nd PLAYER COCKTAIL

SR1 is LEFT
SR2 is UP
SR3 is RIGHT
SR4 is DOWN
SR5 is FIRE

9. SL6 is TEST

10. START 2 is RESET.