



Kurz-Kasch, Inc.


Electronics Division
 Box 1246
 2876 Culver Ave.
 Dayton, Ohio 45401
 Telephone (513) 296-0330

Operating Instructions

For Model 195 A

CKIDZO

Meadows



1. Insert 195 A card into program "A" connector, number side up.
2. Insert computer board into test fixture using 22 pin orientation.
3. Push POWER switch to ON.
4. Push 5 VOLT switch to ON.
5. Push COIN switch once for 2 players, twice for 4 players.
6. SR 1 is NOVICE start.
 SR 2 is EXPERT start.
 SR 3 is PRO start.
7. RRP is WHITE vertical paddle.
 RLP is WHITE horizontal paddle.
 LRP is BLACK horizontal paddle.
 LLP is BLACK vertical paddle.

NOTE: When in 4 player mode we can exercise the other two paddles by switching to 4 PLY on 195 A program card.

8. SR 5 is WHITE speed.
 SL 5 is BLACK speed.